

Addendum 1

IFB Pre-conference Notes

Virtual Meeting

June 5, 2023

This addendum provides notes from the pre-bid conference.

Vendors asked, and DOFAW answered, the following questions:

1. Do we have anything over the 6 ft T posts? The IFB said the post be driven in 2 feet. If the top wire of the panels are clipped to the posts, the posts will be driven in too deep, and couldn't clip to the top wire. Should the T post be higher?
 - a. We think that the T posts should be driven in 20 or 24 inches down, until it feels stable. If there is a need to clip it down on lower strings of the panel, that is ok.

2. With a 6ft T post, perhaps there might need to be driven in lower in boggy areas?
 - a. What we have done is drive a post down around 3 feet, and then attach that into the panel. Then drive another one in 2 feet right next to the first post.